

						E21-E22
1MB	--- 512K	--- 512K	--- ---	--- ---	---	E24-E25 E20-E21
1.64MB	--- 512K	128K ---	--- 512K	--- 512K	---	E24-E25 E21-E22
2MB	--- 512K	--- 512K	--- 512K	--- 512K	---	E24-E25 E21-E22
4.64MB	--- 512K	128K ---	--- 2MB	--- 2MB	---	E24-E25 E20-E21
5MB	--- 512K	--- 512K	--- 2MB	--- 2MB	---	E24-E25 E20-E21
8MB	--- 2MB	--- 2MB	--- 2MB	--- 2MB	---	E24-E25 E20-E21

Note: A dash (---) indicates that a bank is not usable even if it contains memory.

See manual that comes with your expansion board for complete instructions on adding memory.