


CABLE NO.	DESCRIPTION	DRAWING NO.	CABLE ASSY. #
W1	POWER SUPPLY TO MAIN BOARD	0000001	879-3525
W2	AC POWER	0000002	879-3527
W3	SIGNAL - FLOPPY DISK	0000003	879-3533
W4	EARTH GROUND	0000004	879-3447
W5	SPEAKER	0000005	879-3537
W6	879-3478



Connector/Cable Interconnection (8000231)

NOTE: CABLE OR CONNECTOR WILL BE USED IF CABLE THAT IS REQUIRED TO CONNECT TO FLOPPY DISK DRIVES, OTHERWISE USE CABLE ORS ORS ORS ORS