

Note: Refer to Faxback Doc. # 1377 for installation location on Main Logic Board.

#### Memory Expansion Options:

##### 256K DRAM kit

The 25-1079 consists of eight 256K X 1 DRAMS at 150 nanoseconds.

##### Memory Boards

The √25-1062 is a plus-style board which comes with 128K of RAM.

The √25-2062 is a plus-style board which comes fully populated with 512K RAM and comes with software to allow the extra 128K RAM to be used as a RAMDISK.

(This product can be ordered from Tandy National Parts, AX-2502062)

√ = Discontinued Radio Shack Product

Tandy 1000 HX (25-1053) - Expand from 256K:		
	Memory Board	Add to Memory Board
384K	√25-1062	N/A
640K	√25-1062	25-1079
768K	√25-2062	N/A

Note: Use either the 25-1062 or the 25-2062 Memory-Plus board, both boards can not be used at the same time. The 25-2062 board is the preferred upgrade choice.

Jumper Settings:(25-1062 only)			
Board	Memory Kit	Jumper	Total Memory
25-1062	N/A	E1-E2	384K
25-1062	25-1079	E2-E3	640K

(rjs-07/01/93)