

RS-232C Serial Port:

1.	Carrier Detect
2.	Receive Data
3.	Transmit Data
4.	Data Terminal Ready
5.	Signal Ground
6.	Data Set Ready
7.	Request to Send
8.	Clear to Send
9.	Ring Indicator
10	Not Connected

NOTE: THE Z-PDA SERIAL PORT REQUIRES A SPECIAL CABLE. Order Faxback Doc. # 2503 for more information on purchasing the correct cable.

(jlc-01/31/94)