

1. Press and hold the LINE/FORM button.
2. Turn on the printer.

The printer prints the ASCII 96 characters in various fonts programmed into the printer.

The self test printout also provides information about your printer.

Self Test
Press and hold the Line/Form button while turning on the printer.
The self test feature also shows:
The Printer Model
The Firmware Revision Number
The Firmware Part Number
The Character Generator Revision Number
The Character Generator Part Number