

You can use three types of fonts with your printer:

- * Internal (sometimes called resident) fonts are provided with the printer.
- * Font cards can be installed in your printer. These are available by special order through you local Radio Shack store.
- * Downloadable fonts are available through many word processing and desktop publishing software packages. You can also purchase downloadable fonts from several software manufacturers who specialize in creating fonts for laser printers. For instructions for using downloadable fonts, see the user's manual for your software.

AVAILABLE FONTS

For a printout of the resident fonts available through the selected emulation mode and of any additional fonts available through installed font cards or downloaded from software, print the Font List as described in "Self Tests."

The internal fonts available for the HP LaserJet Series II emulation mode are shown in Appendix 1. For a list of internal fonts available in other emulation modes, see the LP-990 Technical Reference Manual.

For information about fonts available through your software, see the user's manual for your software.

SPECIFYING THE FONT SOURCE

You specify the font source through the printing menu. The factory setting is I for internal fonts. If you install a font card, you must change the font source to A or B to indicate the appropriate font card slot.

If you uses software with downloadable fonts, this overrides the font source you specify through the printing menu.

SPECIFYING THE FONT

If your software lets you specify the font, this overrides the printing menu setting. If not, you specify the font by selecting the font number setting in the printing menu.

INSTALLING A FONT CARD

Following these steps to install a font card

1. Be sure the DATA indicator is off. Then, press ONLINE so that the ONLINE indicator turns off.
2. With the font card face up, insert its grooved end into a font card slot (A or B).
3. Change the printer's font source menu setting to A or B to specify the appropriate font card slot. See "Menu Settings."

CAUTION: Installing a font card when the DATA or ONLINE indicator is on might cause erratic printing and damage the printer.

INTERNAL FONTS

The following list shows the fonts provided with the printer in the HP LaserJet Series II Emulation Mode.

FONT#	TYPEFACE	POINT	PITCH	SYMBOL SET	PORTRAIT/LANDSCAPE
00	Courier	12	10	ROMAN-8	PORT
01	Courier	12	10	IBM-US	PORT
02	Courier	12	10	IBM-D/N	PORT
03	Courier	12	10	ECMA-94	PORT
04	Courier Bold	12	10	ROMAN-8	PORT
05	Courier Bold	12	10	IBM-US	PORT
06	Courier Bold	12	10	IBM-D/N	PORT
07	Courier Bold	12	10	ECMA-94	PORT
08	Line Printer	8.5	16.7	ROMAN-8	PORT
09	Line Printer	8.5	16.7	IBM-US	PORT
10	Line Printer	8.5	16.7	IBM-D/N	PORT
11	Line Printer	8.5	16.7	ECMA-94	PORT
12	Courier	12	10	ROMAN-8	LAND
13	Courier	12	10	IBM-US	LAND
14	Courier	12	10	IBM-D/N	LAND
15	Courier	12	10	ECMA-94	LAND
16	Courier Bold	12	10	ROMAN-8	LAND
17	Courier Bold	12	10	IBM-US	LAND
18	Courier Bold	12	10	IBM-D/N	LAND
19	Courier Bold	12	10	ECMA-94	LAND
20	Line Printer	8.5	16.7	ROMAN-8	LAND
21	Line Printer	8.5	16.7	IBM-US	LAND
22	Line Printer	8.5	16.7	IBM-D/N	LAND

APPENDIX 2: INTERNAL SYMBOL SETS

The following list shows the symbols sets provided with the printer for the HP LaserJet Series II Emulation Mode.

SYMBOL SET #	DISPLAY	SYMBOL SET
8U	ROMAN-8	ROMAN-8
0N	ECMA-94	ISO 100 LATIN 1
10U	IBM-US	PC-8
11U	IBM-D/N	PC-8 Denmark/Norway
2U	ISO-2	ISO IRV
1E	ISO-4	ISO United Kingdom
0U	ISO-6	ANSI ASCII (USAASCII)
3S	ISO-10	ISO Swedish
0S	ISO-11	ISO Swedish:Names
0K	ISO-14	JIIIS ASCII
0I	ISO-15	ISO Italian
4S	ISO-16	ISO Portuguese
2S	ISO-17	ISO Spanish

1G	ISO-21	ISO German
0F	ISO-25	ISO French
2K	ISO-57	ISO Chinese
0D	ISO-60	ISO Norwegian v1
1D	ISO-61	ISO Norwegian v2
1F	ISO-69	ISO French
5S	ISO-84	ISO Portuguese:IBM
6S	ISO-85	ISO Spanish:IBM
0G	GERMAN	HP German
1S	SPANISH	HP Spanish

(smm 07/27/93)