


**MODEL 10 VIDEO CASSETTE
PLAYER TRANSPORT MECHANISM
SHEET # 1 (160-0403)
FAXBACK DOC # 10660**



**MODEL 10 VIDEO CASSETTE
PLAYER TRANSPORT MECHANISM
SHEET # 2 (160-0403)
FAXBACK DOC # 10660**

