

# Technical Note

**TITLE:** Infinia Freezes when Radio is used in Sleep Mode

**DATE:** 02/12/97

**PRODUCT FIELDS:** 7130 / Infinia  
Accessory

---

Toshiba America Information Systems, Inc. has done its best to ensure the accuracy of this information. Toshiba America Information Systems, Inc. reserves the right to revise or make obsolete some or all of the contents without obligation to notify any person of such revisions or changes. Despite every effort to the contrary, errors, omissions or discrepancies may have occurred in preparation of this document and Toshiba America Information Systems, Inc. assumes no liability for damages incurred due in part or in whole to such errors.

---

## INFORMATION:

### Problem:

Infinia Freezes When Radio is Used in Sleep Mode

### Cause:

When the FM radio function is activated (1. By pressing the radio button on the InTouch module; 2. Start-Infinia-Toshiba FM Radio; or 3. Double-click Infinia icon on desktop, Double-click Toshiba FM Radio icon), if no preset memory channels have been set, a window is displayed that says "The Toshiba FM Radio application has not detected any radio station presets..." There is a place for a check mark in front of the statement "Do not notify me again about non-existent presents." and an OK button. When this window is displaying, the InTouch module is not functional. Consequently, when the computer is in sleep mode and the FM radio is activated from the InTouch module, the mentioned window is "displayed" (although hidden) with no way to click on OK.

### Resolution:

There are two ways to solve this problem:

1. Put a check mark in front of the "Do not notify me again about non-existent presets", and click on OK; or
2. Set at least one preset/memory station.
  - a. With the FM radio application (and graphic displaying) click on the "^" above "SEEK" to find a station.
  - b. Click on "MEMORY".
  - c. Click on "1"

Note: If the above mentioned window is not seen, it can be brought back by deleting the following file: c:\program files\Toshiba Radio\Toshrad.dat

It will be recreated when the FM radio function is activated.

**Keywords:**

Infinia 7130 7160 7200 FM Radio